

GATEWAY ENTRANCE MATTING



Cleaning guidance

Volume and type of traffic

The following cleaning and maintenance procedures are recommended to ensure the product maintains its desired appearance and effective performance, as well as ensuring a long life span for the product. The cleaning regime will depend on traffic volume over the entrance system, together with the level of soil in areas prior to the entrance. If the entrance system is allowed to become saturated with dirt and debris it will prove more difficult to restore. Regular cleaning appropriate to soiling is therefore recommended.

Daily cleaning

Vacuum with an industrial cleaner, preferably using a driven brush to agitate the pile of the absorbent inserts. Should stones, salt particles or other solid matter become embedded between the surface ribs, remove using a blunt instrument (screwdriver) or similar device.

Chewing gum and stain removal

In addition to daily routine above, its important to remove chewing gum deposits and stains as they appear. Failure to keep up regular gum removal may attract further deposits.



Weekly cleaning

Manual Dry Cleaning

Clean the top surface using a long handed deck scrub or similar brush that will not leave fibres on the mat. Be sure to scrub in both directions to clean the top ribs as well as the tread surface of the PVC grid. Apply a "Dry method" cleaning compound to surface of mat. Brush and agitate compound in all areas of mat until compound is fully absorbed. If possible leave for 30 minutes then vacuum and brush until all compound is removed.



Machine and Wet Cleaning

Follow routine of manual cleaning, then clean top surface using cylindrical brush machine. Initially work in direction of top ribs then across the ribs to complete cleaning.

If a cylindrical brush machine is not available equally good results can be achieved using a high-pressure water extraction process. In areas of abundant salt build up, apply a pre soak solution of vinegar and water (1:20 mix) to the surface prior to machine cleaning.

Matwell cleaning

- 1) Dependent on the density of traffic and level of soiling, it may become necessary to effect a thorough cleaning of the Gateway Entrance Systems and the recessed well.



DRY METHOD
CLEANING SOLUTION
COARSE BRUSH
DAMP CLOTH
CYLINDRICAL BRUSH
MACHINE
VACUUM CLEANER

Plastex Matting Inc.

120 55th St NE
Fort Payne, AL 35967
+1 256 845 7725

USA + UK manufactured
matting products:
plastexmatting.com

GATEWAY ENTRANCE MATTING



Cleaning guidance

Matwell cleaning

- 2) Carefully lift and remove each section of Gateway Entrance Matting one at a time. Roll up and tag each mat section to identify its location and orientation in the mat recess. It is very important that care is taken not to over stretch the sections of matting during removal.
- 3) Start from the centre of the installation and use a blunt instrument (screwdriver) or similar tool to lift the sections of the mat.
- 4) Once all of the Gateway sections have been removed vacuum/sweep the recess thoroughly, ensuring to pick up all stones or grit particles.
- 5) Replace the matting sections as originally laid working from the edges to the centre of the installation. When installing the sections at the edge of the frame, be sure to slide them under the frame lips.
- 6) Perform the weekly cleaning regime previously detailed.
- 7) Check fastness of all screws on aluminum edging/framing, clean with any commercial aluminum cleaner if required.



View the video instructions at <https://youtu.be/U892GGus3TI>

